OVOCOľ

AVW-5555

V032/IOT V25 Firmware Installation Instructions

Introduction

The following guide describes the steps required to update all system firmware of the Avocor AVW-5555 All in one Display.



Scaler Firmware V032

Note

The Scaler Firmware V032 must be upgraded BEFORE the IOT Firmware V25.

- 1. Download *scaler_AVW-5555_V032.bin* for your Avocor display model and save it to a FAT32 compatible USB flash drive.
- 2. Rename the file **merge**.bin.
- 3. Plug the USB flash drive into the **Service Port** on the display.



- 4. Open the OSD for the display and navigate to Adv Settings>Firmware Update
- 5. Select "Yes" when prompted to confirm installation.
- 6. Do not turn off the display until the installation has finished.
- Once the update is complete perform a factory reset by navigating to Adv Settings>Restore Factory Default

IOT Firmware V25

- 1. Download *MERGE_IOT55_V25.bin* and save it to a FAT32 compatible USB flash drive.
- 2. Rename the file **MERGE_IOT**.bin
- 3. Plug the USB flash drive into the Service Port on your AVW-5555.



- 4. Open the OSD for the display and navigate to Adv Settings>IoT Firmware Update
- 5. Select "Yes" when prompted to confirm installation.
- 6. Do not turn off the display until the installation has finished.
- 7. Once the update is complete initiate a Factory Reset by navigating to Adv Settings>Restore Factory Default.

